



- 1. Trykdigningsventil
- 2. Ekspansionsbeholder
- 3. Afspærringsventil
- 4. Stepmotor flowregulering
- 5. Flowsensor

- 6. Sikkerhedsventil 7 Bar
- 7. Kontraventil
- 8. Returtermostatventil
- 9. Snavsfilter
- 10. Tilslutning 3/4" n
- 11. Brugsvandsbeholder 160 l